

How to make a

Cockroach Killer





## Someone I want to appreciate

## George







## Capitan Gi

But I still don't know where he had helped me.



#### Lab 717

Every time if I need some things




## Because they never lock their door.




## Design Diagram


## Design Diagram



#### Website




## Steps




- 1. Train a Volo v8 model
- 2. Set up Camera module
- 3. Deploy to Raspberry
- 4. Streaming camera video to 127.0.0.1:8888
- 5. Detect Cockroach by Yolo v8
- 6. Use SG90 to make a Hitter
- 7. Demo



#### Train a Volo v8 model




## Prepare photo



2024/1/5

#### Label data








```
model = YOLO('yolov8n.yaml') # build a new model from YAML
model = YOLO('yolov8n.pt') # load a pretrained model (recommended for training)
model = YOLO('yolov8n.yaml').load('yolov8n.pt') # build from YAML and transfer weights
# Train the model
results = model.train(data='cockroach.yaml', epochs=500, batch = -1, imgsz=640)
Plotting labels to runs/detect/train2/labels.jpg...
optimizer: 'optimizer=auto' found, ignoring 'lr0=0.01' and 'momentum=0.937' and determining best 'optimizer', 'lr0' and 'momentum' automatically...
optimizer: AdamW(lr=0.002, momentum=0.9) with parameter groups 57 weight(decay=0.0), 64 weight(decay=0.0006171875), 63 bias(decay=0.0)
500 epochs...
     Epoch
                       box_loss cls_loss
                                            dfl_loss Instances
                                                                     Size
                9.34G
     1/500
                          2.338
                                     4.736
                                               1.898
                                                                                         | 1/1 [00:00<00:00, 3.16it/s]
                Class
                         Images Instances
                                               Box(P
                                                                    mAP50 mAP50-95): 100% 1/1 [00:00<00:00, 1.62it/s]
                                                                                                                                                                                                   0.0253
                                                                                                                                                                                                             0.00524
                       box loss cls loss
                                            dfl loss Instances
                                                                     Size
     Epoch
              GPU mem
                                                                                        | 1/1 [00:01<00:00, 1.24s/it]
     2/500
                9.25G
                          2.228
                                     4.597
                                               1.799
                                                                      640: 100%
                Class
                         Images Instances
                                               Box(P
                                                                    mAP50 mAP50-95): 100% 1/1 [00:01<00:00, 1.65s/it]
                                                                                                                                                  all
                       box loss cls loss
                                            dfl loss Instances
                                                                     Size
     Epoch
              GPU mem
                                                                                     | 1/1 [00:00<00:00, 1.44it/s]
                                     4.589
                                               1.819
     3/500
                8.86G
                          2.295
                                                                    mAP50 mAP50-95): 100%| 1/1 [00:01<00:00, 1.04s/it]
                                                                                                                                                  all
                Class
                         Images Instances
                                               Box(P
                                                                                                                                                                             0.00301
                                                                                                                                                                                                   0.0257
                                                                                                                                                                                                             0.00531
                       box loss
                                 cls loss
                                            dfl loss Instances
                                                                     Size
     4/500
                9.25G
                          2.227
                                     4.477
                                               1.808
                                                           121
                                                                                         | 1/1 [00:00<00:00, 1.77it/s]
                Class
                         Images Instances
                                               Box(P
                                                                    mAP50 mAP50-95): 100% 1/1 [00:00<00:00, 2.04it/s]
                                                                                                                                                  all
                                                                                                                                                                              0.0029
                                                                                                                                                                                          0.871
                                                                                                                                                                                                   0.0236
                                                                                                                                                                                                             0.00497
```

2024/1/5

### Get the weight file



And we will use it later

## Set up the Camera module

```
+-/\-\-
| (°) | libcamera
+---+
```

#### There is too much blood and tear


So, Let's skip them



- 1. Train a Volo v8 model
- 2. Set up Camera module
- 3. Deploy to Raspberry
- 4. Streaming camera video to 127.0.0.1:8888
- 5. Detect Cockroach by Yolo v8
- 6. Use SG90 to make a Hitter
- 7. Demo




## Hitter







## Available Range and anchor




## Let's Demo

# Something Still On the way

## Cleaner




#### Available



#### **Problems**

是在轉三小



2024/1/5

## **Streaming Website**

```
Camera __init__ sequence did not complete.
Traceback (most recent call last):
   File "/usr/lib/python3/dist-packages/picamera2/picamera2.py", line
        self._open_camera()
   File "/usr/lib/python3/dist-packages/picamera2/picamera2.py", line
        self.camera.acquire()
RuntimeError: Failed to acquire camera: Device or resource busy
During handling of the above exception, another exception occurred:
```

2024/1/5

#### The Camera is holding when I want

to launch Flask and PiCamera2 at

the same time.



## Thanks